

the No-Mess Waffle™

Instruction Book - BWM520



Breville®



Contents

- 2 Limited Product Warranty
- 2 Breville® Recommends Safety First
- 6 Components
- 7 Operating
- 8 Care and Cleaning



Limited Product Warranty

Breville's warranty for this product covers the repair or replacement if it's found to be defective due to faulty materials, workmanship, or function within the warranty period. All legal warranty rights under applicable national legislation will be respected and will not be impaired by our warranty. For details on length of warranty, to obtain a printed copy or to read full terms

and conditions please scan the QR code or visit www.breville.com. Alternatively, call the Breville Service Centre (see back cover for contact details).



QR149

BREVILLE® RECOMMENDS SAFETY FIRST

At Breville® we are very safety conscious. We design and manufacture appliances with your safety foremost in mind. We also ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

IMPORTANT SAFEGUARDS

Read all instructions before use and save for future reference.

- Remove and safely discard any packaging material and promotional labels before use.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this appliance.
- Always ensure the appliance is properly assembled before use. Follow the instructions provided in this book.
- Do not touch hot surfaces. Appliance surfaces are hot during and after operation. To prevent burns or personal injury, always use protective hot pads or

insulated oven mitts, or use handles where available.

- Do not place the appliance near the edge of a bench or table during operation. Ensure that the surface is dry, level, clean and free of any liquid and other substances.
- Always operate the appliance on a stable and heat resistant surface. Do not use on a cloth-covered surface, and position the appliance at a minimum distance of 20cm away from walls, curtains, cloths and other heat sensitive materials.
- Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.
- Do not operate the appliance on a sink drain board.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Unwind the power cord fully before use.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- Connect only to a 220V power outlet.
- To protect against electric shock, do not immerse the power cord, power plug or appliance in water or any other liquid.
- Always turn the appliance to the OFF position, switch off at the power outlet, remove the plug and allow all parts to cool before attempting to move the appliance, when the appliance is not in use, before cleaning and when storing.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to regularly inspect the appliance. Do not use the appliance if the power cord, power plug or appliance

becomes damaged in any way. Return the entire appliance to the nearest authorised Breville® Service Centre for examination and/or repair.

- Any maintenance, other than cleaning, should be performed at an authorised Breville® Service Centre.
- The use of attachments not sold or recommended by Breville® may cause fire, electric shock or injury.
- This appliance is for household use only. Do not use this appliance for other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- The appliance is not intended to be operated by means of an external timer or separate remote control system.
- When operating the appliance, ensure the power cord is kept away from any heat source including the surface of the appliance. Ensure the power cord does not become trapped between the upper and lower hot plates of the appliance during use and storage.
- Do not place anything on top of the appliance lid when the lid is closed, when in use and when stored.

- Do not use harsh abrasives, caustic cleaners or oven cleaners when cleaning this appliance. Keep the appliance clean and refer to care and cleaning section.
- Do not attempt to operate the appliance by any method other than those described in this booklet. Do not leave the appliance unattended when in use.

The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.



To protect against electric shock or fire, do not immerse the power cord, power plug or appliance in water or any other liquid.

SHORT CORD INSTRUCTIONS

Your Breville® appliance is fitted with a short power supply cord to reduce personal injury or property damage resulting from pulling, tripping or becoming entangled with a longer cord. If an extension cord is used, (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, (2) the cord should be arranged so that it will not drape over the countertop or table-top where it can be pulled on by children or tripped over unintentionally and (3) the extension cord must include a 2-prong grounding plug.

BREVILLE ASSIST™ PLUG

Your Breville® appliance comes with a unique Assist™ Plug, conveniently designed with a finger hole to ease removal from the wall outlet. For safety reasons it is recommended you plug your Breville® appliance directly into its own electrical outlet on a dedicated circuit separate from other appliances. If the electric circuit is overloaded with other appliances, your appliance may not function properly. It is not recommended to use with a power strip.



Hot Surfaces
Do Not Touch

This symbol indicates, temperature of accessible surfaces may be high when the appliance is operating and for some time after use.

FOR HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS



Components



- A. POWER / DARKNESS Control dial
- B. Die-cast aluminium cooking plate
- C. Non-stick cooking surface
- D. Integrated moat
- E. Stainless steel housing

- F. Locking latch
- G. POWER light
- H. READY light



Operating

BEFORE FIRST USE

Before first use, remove and safely discard any packing material, promotional labels and tape from the waffle maker.

1. Wipe the waffle maker cooking plates with a damp sponge or cloth. Dry thoroughly and close the lid.
2. Place the waffle maker on a flat, dry surface. Ensure there is a minimum distance of 20cm of space on all sides of the waffle maker. Do not place anything on top of the waffle maker.
3. Unwind the power cord completely and insert the power plug into a grounded 220V power outlet.
4. Turn the POWER / DARKNESS Control Dial clockwise to the desired setting to start preheating the waffle maker. The POWER light will be illuminated.
5. Use the POWER / DARKNESS control dial to adjust the brownness of your waffle. There are 7 darkness settings ranging from 1 (lightest) to MAX (darkest). Rotate the dial clockwise to increase the brownness or counter-clockwise to decrease it.
6. Once the waffle maker has completed preheating, three audible alerts will sound and the READY light will illuminate.
7. Open the lid and pour approximately 125ml of batter evenly on the centre of the waffle plate. The batter should cover the peaks of the waffle plate.



NOTE

When using the waffle maker for the first time you may notice a fine smoke haze. This is caused by the initial heating of some of the components and is not a cause for concern.

8. Close the lid but keep the locking latch open. As the cooking cycle progresses the READY light will switch off.
9. At the end of the cooking cycle, three audible alerts will sound and the READY light will illuminate. Open the lid and carefully remove your waffles.



NOTE

There can be slight variations between cooking cycles. If your waffles are not at your desired darkness, close the lid and cook for an additional minute.

10. For the most consistent results, add the next batch of batter immediately after removing the cooked waffle and repeat steps 7 through 9.



NOTE

If the next batch of batter is not added immediately after removing the cooked waffle, close the lid and allow the waffle maker to properly reheat (the READY light will switch off and then back on) before adding batter.

11. If you are not cooking any more waffles, turn the POWER / DARKNESS control dial to the OFF position.



Care and Cleaning

- Before cleaning, ensure the POWER / DARKNESS control dial is set to the OFF position and then remove the power plug from the power outlet.
- Allow your waffle maker to cool slightly before cleaning. The waffle maker is easier to clean when slightly warm.
- Always clean your waffle maker after each use to prevent a build-up of baked-on foods. Wipe cooking plates and overflow moat with a soft cloth to remove food residue.

NON-STICK COATING

The cooking plates, hinges and overflow moat are coated with a non-stick finish. This minimises the need for oil, prevents food from sticking, and makes cleaning easier.

Do not use metal or other abrasive cleaning tools on non-stick surfaces as they will damage the coating. Use only warm soapy water and remove stubborn residue with a non-abrasive plastic scouring pad or nylon brush.



NOTE

Do not use non-stick cooking sprays as they can impact the performance of the non-stick surface on the cooking plates.

STORAGE

To store your waffle maker:

1. Ensure the POWER / DARKNESS control dial is set to the OFF position and then unplug power cord from the power outlet.
2. Allow the waffle maker to cool completely.
3. Set the locking latch to the locked position.
4. Wrap the power cord in the cord wrap area below the waffle maker.
5. Store the waffle maker on a flat, dry level surface.



NOTE

The locking latch should not be used when batter is in the cooking plates.

the No-Mess Waffle™

설명서 - BWM520



Breville®



목차

- 10 제한적 제품 보증
- 10 Breville® 은 안전을 최우선으로 생각합니다
- 14 부품
- 15 조립
- 16 관리 및 청소



제한적 제품 보증

이 제품에 대한 Breville의 보증은 보증 기간 이내에 잘못된 소재, 제조 공정 또는 기능으로 인해 결함이 있는 것으로 밝혀진 경우, 수리 또는 교체를 제공합니다.

해당 국가의 법률에 따른 모든 법적 보증 권리는 존중되며 당사의 보증은 이에 영향을 미치지 않습니다. 보증 기간에 대한 자세한 정보, 인쇄본 또는 전체 이용 약관을 확인하려면 QR



QR149

코드를 스캔하거나
www.breville.com을
 방문하시기 바랍니다.
 Breville 서비스 센터를 통한
 문의도 가능합니다
 (연락처는 뒷면 참조).

BREVILLE®은 안전을 최우선으로 생각합니다

Breville®은 안전을 매우 중요하게 생각합니다. 당사는 소중한 고객의 안전을 최우선으로 생각하여 제품을 설계하고 제조합니다. 아울러 제품을 사용할 때는 각별한 주의를 기울이고 다음의 예방 가이드를 준수해 주시기 바랍니다.

중요 안전 지침

사용하기 전에 모든 지침을 읽고 나중에 참조할 수 있도록 잘 보관해 두시기 바랍니다.

- 사용하기 전에 모든 포장재와 판촉 라벨을 제거하고 안전하게 폐기하십시오.
- 어린이의 질식 위험을 방지하기 위해 이 제품의 전원 플러그에 장착된 보호 커버를 제거하고 안전하게 폐기하십시오.
- 사용하기 전에 항상 제품이 올바르게 조립되었는지 확인하십시오. 본 설명서에 명시된 지침을 따르시기 바랍니다.
- 뜨거운 표면을 만지지 마십시오. 제품 표면은 작동 중과 작동 후에 뜨겁습니다. 화상 또는 부상을 방지하기 위해 손잡이를 사용하고, 항상 보호용 핫 패드 또는 단열 오븐 장갑을 사용하십시오.
- 작동 중 제품을 조리대나 테이블 가장자리 근처에 두지

마십시오. 표면이 건조하고, 평평하고, 깨끗하며 액체와 기타 물질이 없는지 확인하십시오.

- 항상 안정적이고 내열성이 있는 표면에서 제품을 사용하십시오. 천으로 덮인 표면에서 사용하지 말고 제품을 벽, 커튼, 천 및 기타 열에 민감한 소재에서 최소 20cm 떨어진 곳에 놓으십시오.
- 고압가스, 전기 버너의 위나 근처, 또는 가열된 오븐에 닿을 수 있는 곳에 이 제품을 놓지 마십시오.
- 제품을 싱크대 식기 건조판에 놓고 작동하지 마십시오.
- 모든 전기 제품에 대한 중요 안전 지침
- 사용하기 전에 전원 코드를 완전히 푸십시오.
- 전원 코드가 조리대나 테이블 가장자리에 걸리거나, 뜨거운 표면에 닿거나 꼬이지 않도록 주의하십시오.
- 220V 전원 콘센트에만 연결하십시오.
- 감전 위험이 있으므로 전원 코드, 전원 플러그, 제품을 물이나 기타 액체에 담그지 마십시오.
- 제품을 이동하거나, 사용하지 않을 때, 청소 및 보관하기 전에 항상 제품의 스위치가 '끄기 (OFF)' 위치에 있는지 확인한 다음, 전원 콘센트의 전원을 끄고 전원 콘센트에서 플러그를 뽑은 후 모든 부품을 식히십시오.
- 8세 이상의 어린이 및 신체적, 감각적, 정신적 능력 및 경험과 지식이 부족한 사람도 제품을

안전하게 사용하는 방법에 관해 감독 또는 지침이 주어지고 관련된 위험을 이해하는 경우 이 제품을 사용할 수 있습니다. 제품을 어린이의 손에 닿지 않는 곳에 두십시오. 8세 미만의 어린이가 보호자의 감독 없이 청소 및 사용자 유지 보수를 하지 않도록 하십시오.

- 제품과 코드를 8세 미만 어린이의 손이 닿지 않는 곳에 보관하십시오.
- 어린이가 제품을 가지고 놀지 않도록 하십시오.
- 제품을 정기적으로 검사하는 것이 좋습니다. 전원 코드, 전원 플러그, 제품이 어떤 식으로든 손상된 경우에는 제품을 사용하지 마십시오. 검사 및/또는 수리가 필요한 경우, 가까운 공인 Breville® 서비스 센터에 제품 전체를 맡기십시오.
- 모든 유지관리(청소 제외)는 공인 Breville® 서비스 센터에서 수행해야 합니다.
- Breville®에서 판매하거나 권장하지 않는 부속품을 사용하면 화재, 감전 또는 부상을 초래할 수 있습니다.
- 본 제품은 가정용입니다. 이 제품을 원래 용도 이외의 목적으로 사용하지 마십시오. 움직이는 차량, 선박 또는 야외에서 사용하지 마십시오. 잘못 사용하면 부상을 입을 수 있습니다.
- 본 제품은 외부 타이머나 별도의 원격 제어

시스템으로 작동하도록 제작되지 않았습니다.

- 제품 작동 시 전원 코드가 제품 표면을 포함한 열원으로부터 멀리 떨어져 있는지 확인하십시오. 사용 및 보관 시 전원 코드가 제품의 상부 및 하부의 고온 플레이트 사이에 끼이지 않도록 하십시오.
- 뚜껑을 닫았을 때, 사용 중일 때, 보관할 때를 비롯하여 제품 뚜껑 위에 아무것도 올려놓지 마십시오.
- 제품 청소 시 거친 연마제, 부식성 세제나 오븐 세제를 사용하지 마십시오. 제품을 깨끗하게 유지하고 관리 및 청소 지침을 참조하십시오.
- 본 설명서에 설명된 방법 이외의 방법으로 제품을 작동하지 마십시오. 사용 중 자리를 비워 제품을 방치하지 마십시오.
- 전기 제품을 사용할 때는 추가적인 안전 보호를 위해 누전 차단기(안전 스위치)를 설치하는 것이 좋습니다. 제품에 전기를 공급하는 전기 회로에 정격 잔류 작동 전류가 30mA 이하인 안전 스위치를 설치하는 것이 좋습니다. 전문적인 조언은 전기 기술자에게 문의해 주십시오.

 감전이나 화재 위험이 있으므로 전원 코드, 전원 플러그, 제품을 물이나 기타 액체에 담그지 마십시오.

짧은 코드 관련 지침

긴 코드를 잡아당기거나, 코드에 걸려 넘어지거나, 얽힘으로 인해서 발생하는 부상 또는 재산 피해를 줄이기 위해 Breville® 제품에는 짧은 전원 공급 코드가 장착되어 있습니다. 연장 코드를 사용할 경우, (1) 코드 세트 또는 연장 코드의 표시된 전기 정격은 최소한 제품의 전기 정격 이상이어야 합니다. (2) 코드는 어린이가 잡아당기지 않아야 하며, 걸려 넘어질 수 있는 조리대나 테이블 상판 위에 늘어지지 않도록 배치 하십시오. (3) 연장 코드에는 2구 접지 플러그가 포함되어야 합니다.

BREVILLE ASSIST™ 플러그

Breville® 제품에는 벽면 콘센트에서 플러그를 쉽게 분리할 수 있도록 ‘손가락 구멍’이 있는 Assist™ 플러그가 함께 제공됩니다. 안전상의 이유로 Breville® 제품을 다른 제품과 분리된 전용 회로의 자체 전기 콘센트에 직접 연결하는 것이 좋습니다. 다른 제품으로 인해 전기 회로에 과부하가 발생하면 제품이 올바르게 작동하지 않을 수 있습니다. 멀티탭과 함께 사용하는 것은 권장하지 않습니다.



이 기호는 제품이 작동 중일 때와
사용 후 일정 시간 이후에도 접근
가능한 표면의 온도가 높을 수 있음
을 나타냅니다.

**해당 제품은 가정용이며,
이 설명서를 보관하시기 바랍니다.**



부품



- A. 전원/굽기(POWER/DARKNESS) 조절 다이얼
- B. 다이캐스트 알루미늄 조리판
- C. 논스틱 코팅 조리 표면
- D. 통합형 넘침 방지 디자인(모트, moat)
- E. 스테인리스 스틸 소재

- F. 잠금 래치
- G. 전원(POWER) 표시등
- H. 준비(READY) 표시등



조립

처음 사용하기 전에

처음 사용하기 전에 와플 메이커에서 포장재, 판촉 라벨 및 테이프를 제거하고 안전하게 폐기하십시오.

1. 젖은 스펀지나 천으로 와플 메이커 조리판을 닦습니다. 완전히 말려 주고 뚜껑을 닫습니다.
2. 와플 메이커를 평평하고 건조한 표면에 놓습니다. 와플 메이커의 모든 면 주변에 최소 20cm의 공간이 있는지 확인합니다. 와플 메이커 위에 아무것도 올려놓지 마십시오.
3. 전원 코드를 완전히 풀고 전원 플러그를 접지된 220V 전원 콘센트에 꽂습니다.
4. 전원/급기(Power/Darkness) 조절 다이얼을 시계 방향으로 돌려 원하는 설정으로 맞추고 와플 메이커를 예열합니다. 전원(Power) 표시등이 켜집니다.
5. 전원/급기(Power/Darkness) 조절 다이얼을 사용하여 와플의 굵기 정도를 조절합니다. 1(가장 약하게 굵기)부터 MAX(가장 세게 굵기) 까지 7단계 굵기 조절 설정이 있습니다. 다이얼을 시계 방향으로 돌려 더 세게, 시계 반대 방향으로 돌려 더 약하게 구울 수 있습니다.
6. 와플 메이커가 예열되면 알림음이 3회 울리고 준비(Ready) 표시등이 켜집니다.
7. 뚜껑을 열고 약 125mL의 반죽을 와플 플레이트 중앙에 고르게 붓습니다. 반죽을 와플 플레이트의 높이에 맞게 붓습니다.



참고

와플 메이커를 처음 사용할 때 미세한 연기가 날 수 있습니다. 이는 일부 구성품이 처음 가열되면서 발생하는 현상이며 제품에 이상이 있는 것이 아닙니다.

8. 뚜껑을 닫고 잠금 래치를 열어 둡니다. 조리 과정이 진행되면 준비(Ready) 표시등이 켜집니다.
9. 조리 과정이 끝나면 알림음이 3회 울리고 준비(Ready) 표시등이 켜집니다. 뚜껑을 열고 와플을 조심스럽게 꺼냅니다.



참고

조리 과정마다 약간의 차이가 있을 수 있습니다. 와플이 원하는 것보다 약하게 구워졌을 경우, 뚜껑을 닫고 1분 더 굽습니다.

10. 가장 일관된 결과를 얻으려면 구워진 와플을 꺼낸 직후 다음 반죽을 넣고 7~8단계를 반복합니다.



참고

구워진 와플을 꺼낸 직후 다음 반죽을 넣지 않은 경우, 뚜껑을 닫고 와플 메이커가 적절하게 재가열(준비(Ready) 표시등이 꺼졌다가 다시 켜짐)되도록 기다린 후 반죽을 추가하십시오.

11. 와플을 더 이상 만들지 않는 경우 전원/급기(Power/Darkness) 조절 다이얼을 '끄기(OFF)' 위치로 돌립니다.



관리 및 청소

관리 및 청소

- 청소하기 전에 전원/급기(Power/DARKNESS) 조절 다이얼을 '끄기(OFF)' 위치로 설정한 다음 전원 콘센트에서 전원 플러그를 분리하십시오.
- 청소하기 전에 와플 메이커를 약간 식히십시오. 와플 메이커가 약간 따뜻한 상태에서 더 쉽게 청소할 수 있습니다.
- 구워진 음식물이 쌓이지 않도록 매번 사용 후에 와플 메이커를 청소하십시오. 부드러운 천으로 조리판과 넘침 방지 모트(moat)를 닦아 음식물 찌꺼기를 제거하십시오.

논스틱 코팅

- 조리판, 힌지, 넘침 방지 모트(moat)는 논스틱 마감으로 코팅되어 있습니다. 따라서 적은 양의 오일만으로도 충분하며 음식이 달라붙지 않고 청소가 더 쉽습니다.
- 코팅이 손상될 수 있으므로 논스틱 표면에는 금속이나 기타 연마성 청소 도구를 사용하지 마십시오. 따뜻한 비눗물만 사용하여 비연마성 플라스틱 수세미나 나일론 세척 솔로 없애기 힘든 잔여물을 제거해 주십시오.



참고

논스틱 조리용 스프레이는 논스틱 조리판 표면의 성능에 영향을 미칠 수 있으므로 사용하지 마십시오.

보관

와플 메이커 보관 방법:

1. 전원/급기(Power/DARKNESS) 조절 다이얼을 '끄기(OFF)' 위치로 설정한 다음 전원 콘센트에서 전원 코드를 뽑습니다.
2. 와플 메이커를 완전히 식힙니다.
3. 잠금 래치를 잠금 위치로 설정합니다.
4. 와플 메이커 아래의 코드 보관 부분에 전원 코드를 감아 넣습니다.
5. 와플 메이커를 평평하고 건조한 수평면에 보관합니다.



참고

반죽이 조리판에 있을 때는 잠금 래치를 사용하지 마십시오.



참고



참고



참고

수입판매원: 브레빌코리아 유한회사
서울특별시 강남구 논현로 159길 41 (신사동)
고객 서비스 센터: 080-822-1691

Breville®
Master Every Moment™

Copyright Breville Pty. Ltd. 2026.

지속적인 제품 개선으로 인해, 본 책자에 담긴 제품 삽화 및 사진은 실제 제품과 약간 다를 수 있습니다.

BWM520 KOR - C26